

# ***NF894V Series***

## ***User's Manual***

**NO. G03-NF894V-F**

**Revision: 3.0**

**Release date: June 26, 2024**

### **Trademark:**

\* Specifications and Information contained in this documentation are furnished for information use only, and are subject to change at any time without notice, and should not be construed as a commitment by manufacturer.

---

## Environmental Protection Announcement

Do not dispose this electronic device into the trash while discarding. To minimize pollution and ensure environment protection of mother earth, please recycle.



---

---

# TABLE OF CONTENT

|  |     |
|--|-----|
| ENVIRONMENTAL SAFETY INSTRUCTION .....           | iii |
| USER'S NOTICE .....                              | iv  |
| MANUAL REVISION INFORMATION .....                | iv  |
| ITEM CHECKLIST .....                             | iv  |
| <b>CHAPTER 1 INTRODUCTION OF THE MOTHERBOARD</b> |     |
| 1-1 FEATURE OF MOTHERBOARD .....                 | 1   |
| 1-2 SPECIFICATION .....                          | 2   |
| 1-3 LAYOUT DIAGRAM .....                         | 3   |
| <b>CHAPTER 2 HARDWARE INSTALLATION</b>           |     |
| 2-1 JUMPER SETTING .....                         | 7   |
| 2-2 CONNECTORS, HEADERS AND WAFERS .....         | 12  |
| 2-2-1 CONNECTORS .....                           | 12  |
| 2-2-2 HEADERS & WAFERS .....                     | 15  |
| <b>CHAPTER 3 INTRODUCING BIOS</b>                |     |
| 3-1 ENTERING SETUP .....                         | 24  |
| 3-2 BIOS MENU SCREEN .....                       | 25  |
| 3-3 FUNCTION KEYS .....                          | 26  |
| 3-4 GETTING HELP .....                           | 26  |
| 3-5 MENU BARS .....                              | 26  |
| 3-6 MAIN MENU .....                              | 27  |
| 3-7 ADVANCED MENU .....                          | 28  |
| 3-8 CHIPSET MENU .....                           | 40  |
| 3-9 SECURITY MENU .....                          | 44  |
| 3-10 BOOT MENU .....                             | 46  |
| 3-11 SAVE & EXIT MENU .....                      | 47  |



## Environmental Safety Instruction

---

- Avoid the dusty, humidity and temperature extremes. Do not place the product in any area where it may become wet.
- 0 to 40 centigrade is the suitable temperature. (The temperature comes from the request of the chassis and thermal solution)
- Generally speaking, dramatic changes in temperature may lead to contact malfunction and crackles due to constant thermal expansion and contraction from the welding spots' that connect components and PCB. Computer should go through an adaptive phase before it boots when it is moved from a cold environment to a warmer one to avoid condensation phenomenon. These water drops attached on PCB or the surface of the components can bring about phenomena as minor as computer instability resulted from corrosion and oxidation from components and PCB or as major as short circuit that can burn the components. Suggest starting the computer until the temperature goes up.
- The increasing temperature of the capacitor may decrease the life of computer. Using the close case may decrease the life of other device because the higher temperature in the inner of the case.
- Attention to the heat sink when you over-clocking. The higher temperature may decrease the life of the device and burned the capacitor.

---

---

## USER'S NOTICE

COPYRIGHT OF THIS MANUAL BELONGS TO THE MANUFACTURER. NO PART OF THIS MANUAL, INCLUDING THE PRODUCTS AND SOFTWARE DESCRIBED IN IT MAY BE REPRODUCED, TRANSMITTED OR TRANSLATED INTO ANY LANGUAGE IN ANY FORM OR BY ANY MEANS WITHOUT WRITTEN PERMISSION OF THE MANUFACTURER.

THIS MANUAL CONTAINS ALL INFORMATION REQUIRED TO USE THIS MOTHER-BOARD SERIES AND WE DO ASSURE THIS MANUAL MEETS USER'S REQUIREMENT BUT WILL CHANGE, CORRECT ANY TIME WITHOUT NOTICE. MANUFACTURER PROVIDES THIS MANUAL "AS IS" WITHOUT WARRANTY OF ANY KIND, AND WILL NOT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING DAMAGES FOR LOSS OF PROFIT, LOSS OF BUSINESS, LOSS OF USE OF DATA, INTERRUPTION OF BUSINESS AND THE LIKE).

PRODUCTS AND CORPORATE NAMES APPEARING IN THIS MANUAL MAY OR MAY NOT BE REGISTERED TRADEMARKS OR COPYRIGHTS OF THEIR RESPECTIVE COMPANIES, AND THEY ARE USED ONLY FOR IDENTIFICATION OR EXPLANATION AND TO THE OWNER'S BENEFIT, WITHOUT INTENT TO INFRINGE.

## Manual Revision Information

| Reversion | Revision History | Date          |
|-----------|------------------|---------------|
| 3.0       | Third Edition    | June 26, 2024 |

## Item Checklist

- Motherboard
- Cable(s)
- I/O Back panel shield

---

# Chapter 1

## Introduction of the Motherboard

### 1-1 Feature of Motherboard

- Onboard Intel® Apollo Lake SoC Series Processor (Default J3455), with low power consumption and high performance
- Support 2\* DDR3L 1866MHz SO-DIMM with maximum memory capacity up to 8GB
- Onboard optional 32GB / 64GB eMMC (by order)
- Integrated with 2\* Intel i226-V 2.5 Gigabit Ethernet LAN chip
- Integrated with Realtek HD Audio Codec
- Support 4\* USB 3.0 data transport demand
- Support 2\* HDMI (one option with DP, Default HDMI)+ 1\* eDP or 1\* LVDS display
- Support 1\* PCIe x1 slot & 1\* full-size Mini-PCIe slot
- Onboard 1\* M.2 M-key (type-2242/2280, SATA interface) slot
- Onboard 1\* SATAIII (6Gb/s) port connector
- Support 9V~36V DC-In
- Support Smart FAN function
- Supports ACPI S3 Function
- Compliance with ErP Standard
- Support Watchdog Timer Technology
- Solution for Industrial Automation, Industrial PPC, KIOSK and Digital Signage


## 1-2 Specification

| Spec           | Description   |
|----------------|---|
| Design         | <ul style="list-style-type: none"> <li>● Mini-ITX form factor; 6-layers; PCB size: 17.0x17.0cm</li> </ul>   |
| CPU            | <ul style="list-style-type: none"> <li>● Intel® Apollo Lake series SoC CPU (Default J3455)</li> <li>* For detailed CPU support information please visit our website</li> </ul>  |
| Memory Slot    | <ul style="list-style-type: none"> <li>● 2* DDR3L SO-DIMM slot</li> <li>● Support DDR3L1866 MHz SODIMM up to 8GB</li> <li>● Support dual channel function</li> </ul>  |
| Expansion Slot | <ul style="list-style-type: none"> <li>● 1* PCIE x 1 slot (<b>PCIEX1</b>)</li> <li>● 1* Full-size Mini-PCIE slot (<b>MPE1</b>)</li> <li>● 1* SIM card slot (<b>SIM CARD</b>)</li> </ul>   |
| Storage        | <ul style="list-style-type: none"> <li>● 1* SATA III 6G/s connector (<b>SATA1</b>)</li> <li>● 1* M.2 M-key,type-2242/2280, SATA interface slot (<b>M.2</b>)</li> </ul>  |
| LAN Chip       | <ul style="list-style-type: none"> <li>● Integrated with 2* Intel i226-V 2.5 Gigabit Ethernet LAN chip</li> <li>● Support Fast Ethernet LAN function of providing 10/100/1000/2500 Mbps Ethernet data transfer rate</li> </ul>  |
| Audio Chip     | <ul style="list-style-type: none"> <li>● Realtek HD Audio Codec integrated</li> <li>● Audio driver and utility included</li> </ul>  |
| BIOS           | <ul style="list-style-type: none"> <li>● AMI Flash ROM</li> </ul>   |
| Multi I/O      | <p><b>Rear Panel I/O:</b></p> <ul style="list-style-type: none"> <li>● 1* 9V~36V DC-IN power jack</li> <li>● 2* HDMI port (one option with DP, Default HDMI)</li> <li>● 2* RJ-45 LAN port</li> <li>● 4* USB 3.0 port</li> <li>● 1* Audio line-out connector</li> </ul> <p><b>Internal I/O Connectors, Headers &amp; Wafers:</b></p> <ul style="list-style-type: none"> <li>● 1* 2-Pin internal 9V~36V power connector</li> <li>● 1* CPU FAN connector</li> <li>● 1* SATA power out connector</li> </ul> |

- 1\* Front panel header
- 1\* Front panel audio header
- 1\* 3W Amplifier wafer
- 1\* LAN Status LED header
- 1\* 9-Pin USB 2.0 header for 2\* USB 2.0/1.1 ports
- 1\* 4-Pin USB 2.0 header for 1\* USB 2.0/1.1 port
- 1\* RS232/422/485 serial port header (**COM1**)
- 5\* RS232 serial port header (**COM2/3/4/5/6**)
- 1\* PS2 Keyboard & Mouse header
- 1\* SMBUS header
- 1\* GPIO header
- 1\* eDP wafer
- 1\* LVDS header
- 1\* LVDS Inverter wafer
- 1\* JSIM header

## 1-3 Layout Diagram

### Rear IO Diagram




### Warning!!

The board has a 9V~36V DC-in power jack (**DCIN3**) in I/O back panel and an internal 9V~36V power connector (**DCIN2**). User can only connect one type of compatible power supply to one of them to power the system.




# Motherboard Internal Diagram



**\*Note:** 1. SIM card slot (**SIMCARD**/ expansion card drawn from **JSIM** header) only work **when** compatible SIM card installed & LAN expansion card installed in the **full-size MPE** slot (**MPE1**); 2. **SIMCARD** and **JSIM** is optional, i.e., only one can work at the same time.

---

## Motherboard Jumper Position



---

---

## Connectors

| Connector       | Name  |
|-----------------|---|
| DCIN3           | 9V~36V DC-in Power Jack                     |
| HDMI2/HDMI1     | HDMI Port Connector X2                      |
| LAN1/LAN 2      | RJ-45 LAN Connector X2                      |
| USB30-1/USB30-2 | USB 3.0 Port Connector X2                   |
| FP_HP           | Audio Line-out Port                         |
| DCIN2           | 2-Pin Internal 9V~36V DC-in Power Connector |
| SATA1           | SATAIII Connector                           |
| SATAPWR1        | SATA Power out Connector                    |
| CPUFAN1         | CPU FAN Connector                           |

## Headers

| Header       | Name   | Description               |
|--------------|--|---------------------------|
| JW_FP        | Front Panel Header(PWR LED/HD LED/Power Button /Reset) | 9-pin Block (2.54 pitch)  |
| FP_AUDIO     | Front Panel Audio Header                               | 9-pin Block (2.0 pitch)   |
| AMP_SPK1     | 3W Amplifier Wafer                                     | 4-pin Block (2.54 pitch)  |
| JLANLED      | LAN Activity Status LED Header                         | 4-pin Block (2.0 pitch)   |
| FP_USB20-1   | USB 2.0 Port Header                                    | 4-pin Block (2.0 pitch)   |
| FP_USB20-2   | USB 2.0 Port Header                                    | 9-pin Block (2.0 pitch)   |
| COM1         | RS232/422/485 Serial Port Header                       | 9-pin Block (2.0 pitch)   |
| COM2/3/4/5/6 | RS232 Serial Port Header                               | 9-pin Block (2.0 pitch)   |
| PS2KBMS      | PS2 Keyboard & Mouse Port Header                       | 6-pin Block (2.0 pitch)   |
| SMBUS        | SMBUS Header   | 5-pin Block (2.0 pitch)   |
| GPIO_CON     | GPIO Port Header                                       | 10-pin Block (2.54 pitch) |
| eDP          | eDP Wafer  | 40-pin Block (1.25 pitch) |
| LVDS         | LVDS Port Header                                       | 32-pin Block (2.0 pitch)  |
| INVERTER     | LVDS Inverter Header                                   | 8-pin Block (2.54 pitch)  |
| JSIM         | SIM Card Expansion Header                              | 6-pin Block (2.0pitch)    |


## Jumper

| Jumper   | Name   | Description              |
|----------|--|--------------------------|
| JCOM1    | COM1 Port Pin9 Function Select   | 4-pin Block (2.0pitch)   |
| JLCD     | LCD Panel VCC Select   | 4-pin Block (2.0 pitch)  |
| JLED     | Inverter Backlight VCC Select  | 3-pin Block (2.54 pitch) |
| JMPE     | MPE1 Slot VCC Select   | 3-pin Block (2.54 pitch) |
| JAT_ATX1 | ATX/AT Mode Select   | 3-pin Block (2.54 pitch) |
| J1       | <b>Pin (1-2):</b> Clear CMOS RAM Settings<br><b>Pin (3-4):</b> RTC Reset<br><b>Pin (5-6):</b> TXE Override<br><b>Pin (7-8):</b> Case Open Function | 8-pin Block (2.0 pitch)  |


# Chapter 2 Hardware Installation

## 2-1 Jumper Setting


**JCOM1 (4-pin): COM1 Port Pin9 Function Select** (2.0 pitch)



## JLCD (4-pin): LCD Panel VCC Select (2.0 pitch)




## JLED (3-pin): LCD Backlight VCC Select (2.54 pitch)




---


**JMPE (3-pin): MPE1 Slot VCC Select** (2.54 pitch)



**JMPE → MPE1 Slot Power VCC Select**




1-2 Closed: MPE Slot Power VCC= 3.3V;




2-3 Closed: MPE Slot Power VCC= 3.3VSB.


**JAT\_AT1 (3-pin): ATX Mode/ AT Mode Select** (2.54 pitch)



**JAT\_AT1 → ATX/AT Mode Select**



1-2 Closed: ATX Mode Selected;




2-3 Closed: AT Mode Selected.


**ATX Mode Selected:** Press power button to power on after power input ready;

**AT Mode Selected:** Directly power on as power input ready.


**Pin 1&2 of J1(8-pin): Clear CMOS RAM Setting** (2.0 pitch)



**Pin 1&2 of J1→Clear CMOS**




1-2 Open: Normal(Default);




1-2 Closed: Clear CMOS(One Touch).


**Pin 3&4 of J1(8-pin): RTC Reset** (2.0 pitch)



**Pin 3&4 of J1→RTC Reset**




3-4 Open: Normal(Default);




3-4 Closed: RTC Reset(One Touch).

---


**Pin 5&6 of J1(8-pin): TXE Override** (2.0 pitch)



**Pin 5&6 of J1→TXE Override**




**3-4 Open: Normal(Default);**




**3-4 Closed: TXE Override.**

**Pin 7&8 of J1(8-pin): Case Open Detection Select** (2.0 pitch)



**Pin 7&8 of J1→Case Open Detection**



**Pin (7&8) Closed:** When Case open function pin short to GND, the Case open function was detected. When used, needs to enter BIOS and enable 'Case Open Detect' function. In this case if your case is removed, next time when you restart your computer, a message will be displayed on screen to inform you of this.



---






---

## 2-2 Connectors, Headers and Wafers


### 2-2-1 Connectors

#### (1) Rear Panel Connectors

\*Refer to Page-3.

| <i>Icon</i>   | <i>Name</i>             | <i>Function</i>   |
|---|-------------------------|---|
|  | <b>DC-In Power Jack</b> | 9V~36V DC-in system power connector<br>For user to connect compatible power adapter to provide power supply for the system.               |
|  | <b>HDMI Port</b>        | To connect display device that support HDMI specification.  |
|  | <b>RJ-45 LAN Port</b>   | This connector is standard RJ-45 LAN jack for Network connection.   |
|  | <b>USB 3.0 Port</b>     | To connect USB keyboard, mouse or other devices compatible with USB specification. USB 3.0 ports supports up to 5Gbps data transfer rate. |
|  | <b>Line-Out</b>         | This connector can functions as audio Line-Out jack and MIC jack with compatible cables & devices.  |

## (2) DCIN2 (2-pin): Internal 9V~36V DC-in power connector




### Warning!!

The board has a 9V~36V DC-in power jack (**DCIN3**) in I/O back panel and an internal 9V~36V power connector (**DCIN2**). User can only connect one type of compatible power supply to one of them to power the system.


## (3) SATA1 (7-pin block):SATAIII Port connector

This connector is a high-speed SATAIII port that supports 6 GB/s transfer rate.




---

**(4) SATAPWR1 (4-pin) : SATA Power-out Connector**




**(5) CPUFAN1 (4-pin): CPU FAN Connector**



---


## 2-2-2 Headers & Wafers

### (1) JW\_FP (9-pin): Front Panel Header (2.54 pitch)




### (2) FP\_AUDIO (9-pin): Line-Out, MIC-In Header (2.0 pitch)


This header connects to Front Panel Line-out, MIC-In connector with cable.



**(3) AMP\_SPK1 (4-pin): 3W Amplifier Wafer (2.54 pitch)**




**(4) JLANLED (4-pin): LAN Activity LED Headers (2.0 pitch)**




---

**(5) FP\_USB20-1 (4-pin): USB 2.0 Port Header (2.0 pitch)**





**(6) FP\_USB20-2 (9-pin): USB 2.0 Port Header (2.0 pitch)**




---

**(7) PS2KBMS (6-pin): PS/2 Keyboard & Mouse Port Header** (2.0 pitch)



**(8) COM1/2/3/4/5/6 (9-pin): Serial Port Header** (2.0 pitch)

**COM1: RS232/422/485 Serial Port Header;**  
**COM2/3/4/5/6: RS232 Serial Port Header.**




| Pin NO. | RS232 | *RS422 | *RS485 |
|---------|-------|--------|--------|
| Pin 1   | DCD   | TX-    | DATA-  |
| Pin 2   | RXD   | TX+    | DATA+  |
| Pin 3   | TXD   | RX+    | NC     |
| Pin 4   | DTR   | RX-    | NC     |
| Pin 5   | GND   | GND    | GND    |
| Pin 6   | DSR   | NC     | NC     |
| Pin 7   | RTS   | NC     | NC     |
| Pin 8   | CTS   | NC     | NC     |
| Pin 9   | RI    | NC     | NC     |

**\*Note:** In the case that COM1 header supports RS422, RS485 function, besides connecting compatible COM cable for RS422 or RS 485 function, user also needs to go to BIOS to set corresponding '**Transmission Mode Select**' for COM1 (refer to Page-28).




---


**(9) SMBUS (5-Pin): SMBUS Header** (2.0 pitch)



**(10) GPIO\_CON (10-pin): GPIO Port Header** (2.54 pitch)




**(11) eDP (40-pin): 4-Lane eDP Wafer** (1.25 pitch)



| Pin NO. | Pin Define | Pin NO. | Pin Define |
|---------|------------|---------|------------|
| Pin 1   | NC         | Pin 21  | NC         |
| Pin 2   | GND        | Pin 22  | NC         |
| Pin 3   | Lane3_N    | Pin 23  | GND        |
| Pin 4   | Lane3_P    | Pin 24  | GND        |
| Pin 5   | GND        | Pin 25  | GND        |
| Pin 6   | Lane2_N    | Pin 26  | GND        |
| Pin 7   | Lane2_P    | Pin 27  | HPD        |
| Pin 8   | GND        | Pin 28  | GND        |
| Pin 9   | Lane1_N    | Pin 29  | GND        |
| Pin 10  | Lane1_P    | Pin 30  | GND        |
| Pin 11  | GND        | Pin 31  | GND        |
| Pin 12  | Lane0_N    | Pin 32  | BL_ENABLE  |
| Pin 13  | Lane0_P    | Pin 33  | BL_PWM_DIM |
| Pin 14  | GND        | Pin 34  | NC         |
| Pin 15  | AUX_CH_P   | Pin 35  | NC         |
| Pin 16  | AUX_CH_N   | Pin 36  | BL_PWR     |
| Pin 17  | GND        | Pin 37  | BL_PWR     |
| Pin 18  | LCD_VCC    | Pin 38  | BL_PWR     |
| Pin 19  | LCD_VCC    | Pin 39  | BL_PWR     |
| Pin 20  | LCD_VCC    | Pin 40  | NC         |


(12) LVDS (32-Pin): 24-bit dual channel LVDS Header (2.0 pitch)



| Pin Define    | Pin NO. | Pin NO. | Pin Define    |
|---------------|---------|---------|---------------|
| GND           | Pin 32  | Pin 31  | GND           |
| LCD_VCC       | Pin 30  | Pin 29  | LCD_VCC       |
| XX            | Pin 28  | Pin 27  | LCD_VCC       |
| LVDSA -DATAN0 | Pin 26  | Pin 25  | LVDSA-DATAP0  |
| LVDSA -DATAN1 | Pin 24  | Pin 23  | LVDSA-DATAP1  |
| LVDSA -DATAN2 | Pin 22  | Pin 21  | LVDSA-DATAP2  |
| LVDSA -CLKN   | Pin 20  | Pin 19  | LVDSA -CLKP   |
| LVDSA -DATAN3 | Pin 18  | Pin 17  | LVDSA -DATAP3 |
| GND           | Pin 16  | Pin 15  | GND           |
| GND           | Pin 14  | Pin 13  | XX            |
| NC            | Pin 12  | Pin 11  | NC            |
| LVDSB -DATAP0 | Pin 10  | Pin 9   | LVDSB -DATAN0 |
| LVDSB -DATAP1 | Pin 8   | Pin 7   | LVDSB -DATAN1 |
| LVDSB -DATAP2 | Pin 6   | Pin 5   | LVDSB -DATAN2 |
| LVDSB -CLKP   | Pin 4   | Pin 3   | LVDSB -CLKN   |
| LVDSB -DATAP3 | Pin 2   | Pin 1   | LVDSB -DATAN3 |


**\*Note:** User can choose between LVDS and eDP display options, but **only one of them can function at the same time**. Before connecting compatible cable to corresponding header/wafer, user should go to BIOS settings→Chipset→ **Uncore Configuration**→ **Active LFP**, and set it as [LVDS] or [eDP] based on actual configuration.

**(13) INVERTER (8-Pin): LVDS Inverter** (2.54 pitch)



**Warning!** Find Pin-1 location of the inverter and make sure that the installation direction is correct! Otherwise serious harm will occur to the board/display panel!!

**(14) JSIM(6-Pin): SIM Card Expansion Header** (2.0 pitch)



---

---

# Chapter 3

## Introducing BIOS

**Notice!** The BIOS options in this manual are for reference only. Different configurations may lead to difference in BIOS screen and BIOS screens in manuals are usually the first BIOS version when the board is released and may be different from your purchased motherboard. Users are welcome to download the latest BIOS version form our official website.

The BIOS is a program located on a Flash Memory on the motherboard. This program is a bridge between motherboard and operating system. When you start the computer, the BIOS program will gain control. The BIOS first operates an auto-diagnostic test called POST (power on self test) for all the necessary hardware, it detects the entire hardware device and configures the parameters of the hardware synchronization. Only when these tasks are completed done it gives up control of the computer to operating system (OS). Since the BIOS is the only channel for hardware and software to communicate, it is the key factor for system stability, and in ensuring that your system performance as its best.

### 3-1 Entering Setup

Power on the computer and by pressing <Del> immediately allows you to enter Setup. If the message disappears before your respond and you still wish to enter Setup, restart the system to try again by turning it OFF then ON or pressing the “RESET” button on the system case. You may also restart by simultaneously pressing <Ctrl>, <Alt> and <Delete> keys. If you do not press the keys at the correct time and the system does not boot, an error message will be displayed and you will again be asked to

```

Please select boot device:

Windows Boot Manager (MMC - BJTD4R)
MMC - BJTD4R
UEFI: Built-in EFI Shell
Enter Setup


↑ and ↓ to move selection
ENTER to select boot device
ESC to boot using defaults

```

Press <Del> to enter Setup/ Press <F7> to enter Popup Menu.

### 3-2 BIOS Menu Screen

The following diagram show a general BIOS menu screen:



---

---

## 3-3 Function Keys

In the above BIOS Setup main menu of, you can see several options. We will explain these options step by step in the following pages of this chapter, but let us first see a short description of the function keys you may use here:

- Press ←→ (left, right) to select screen;
- Press ↑↓ (up, down) to choose, in the main menu, the option you want to confirm or to modify.
- Press <Enter> to select.
- Press <+>/<-> keys when you want to modify the BIOS parameters for the active option.
- [F1]: General help.
- [F2]: Previous value.
- [F3]: Optimized defaults.
- [F4]: Save & Exit.
- Press <Esc> to quit the BIOS Setup.

## 3-4 Getting Help

### Main Menu

The on-line description of the highlighted setup function is displayed at the top right corner the screen.

### Status Page Setup Menu/Option Page Setup Menu

Press [F1] to pop up a small help window that describes the appropriate keys to use and the possible selections for the highlighted item. To exit the Help Window, press <Esc>.

## 3-5 Menu Bars

**There are six menu bars on top of BIOS screen:**

|                 |   |
|-----------------|---|
| <b>Main</b>     | To change system basic configuration    |
| <b>Advanced</b> | To change system advanced configuration |


---

|                        |   |
|------------------------|---|
| <b>Chipset</b>         | To change chipset configuration         |
| <b>Security</b>        | Password settings                       |
| <b>Boot</b>            | To change boot settings                 |
| <b>Save &amp; Exit</b> | Save setting, loading and exit options. |

User can press the right or left arrow key on the keyboard to switch from menu bar. The selected one is highlighted.

### 3-6 Main Menu

Main menu screen includes some basic system information. Highlight the item and then use the <+> or <-> and numerical keyboard keys to select the value you want in each item.





---


## System Date

Set the date. Please use [Tab] to switch between date elements.

## System Time

Set the time. Please use [Tab] to switch between time elements.

## 3-7 Advanced Menu



### OS Selection

The optional settings: [Windows]; [Intel Linux]; [MSDOS].

\* **Note:** User need to go to this item to select the OS mode before installing corresponding OS driver, otherwise problems will occur when installing the driver.

#### ▶ **Trusted Computing**

Press [Enter] to enable or disable 'Security Device Support'.

#### Configuration

---

---

## **Security Device Support**

Use this item to enable or disable BIOS support for security device.

The optional settings: [Disabled]; [Enabled].

### **No Security Device Found**

#### ▶ **ACPI Settings**

Press [Enter] to make settings for the following sub-items:

### **ACPI Settings**

#### **ACPI Sleep State**

Use this item to select the highest ACPI sleep state the system will enter when the suspend button is pressed.

The optional settings are: [Suspend Disabled]; [S3 (Suspend to RAM)].

#### ▶ **Super I/O Configuration**

Press [Enter] to make settings for the following sub-items:

### **Super IO Configuration**

#### ▶ **Serial Port 1 Configuration**

Press [Enter] to make settings for the following items:

### **Serial Port**

Use this item to enable or disable serial port (COM).

The optional settings are: [Disabled]; [Enabled].

When set as **[Enabled]**, the following sub-items shall appear:

### **Device Settings**

#### **Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [Auto]; [IO=3F8h; IRQ=4]; [IO=2F8h; IRQ=3]; [IO=3E8h; IRQ=4]; [IO=2E8h; IRQ=3];

#### **Transmission Mode Select**

The optional settings are: [RS422]; [RS232]; [RS485].

#### **Mode Speed Select**

The optional settings are: [RS232/RS422/RS485=250kbps]; [RS232=1Mbps, RS422/RS485=10Mbps].

---

▶ **Serial Port 2 Configuration**

Press [Enter] to make settings for the following sub-items:

**Serial Port**

Use this item to enable or disable serial port (COM).

The optional settings are: [Disabled]; [Enabled].

When set as **[Enabled]**, the following sub-items shall appear:

**Device Settings**

**Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [Auto]; [IO=3F8h; IRQ=4]; [IO=2F8h; IRQ=3]; [IO=3E8h; IRQ=4]; [IO=2E8h; IRQ=3];

▶ **Serial Port 3 Configuration/ Serial Port 4 Configuration**

Press [Enter] to make settings for the following items:

**Serial Port**

Use this item to enable or disable serial port (COM).

The optional settings are: [Disabled]; [Enabled].

When set as **[Enabled]**, the following sub-items shall appear:

**Device Settings**

**Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [Auto]; [IO=3F8h; IRQ=10]; [IO=2F8h; IRQ=10]; [IO=3E8h; IRQ=10]; [IO=2E8h; IRQ=10]; [IO=2F0h; IRQ=10]; [IO=2E0h; IRQ=10]

▶ **Serial Port 5 Configuration/ Serial Port 6 Configuration**

Press [Enter] to make settings for the following items:

**Serial Port**

Use this item to enable or disable serial port (COM).

The optional settings are: [Disabled]; [Enabled].

When set as **[Enabled]**, the following sub-items shall appear:

**Device Settings**

**Change Settings**

Use this item to select an optimal setting for super IO device.

The optional settings are: [Auto]; [IO=3F8h; IRQ=11]; [IO=2F8h; IRQ=11]; [IO=3E8h; IRQ=11]; [IO=2E8h; IRQ=11]; [IO=2F0h; IRQ=11]; [IO=2E0h; IRQ=11]

---

## **ERP Support**

The optional settings: [Disabled]; [Enabled].

This item should be set as [**Disabled**] if you wish to have all active wake-up functions.

## **Case Open Detect**

Use this item to detect case has already open or not, show message in POST.

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], system will detect if COPEN has been short or not (refer to Page 11); if **Pin 7&8 of J1** is short, system will show Case Open Message during POST.

## **WatchDog Reset Timer**

Use this item to enable or disable WDT reset function. When set as [Enabled], the following sub-items shall appear:

### ***WatchDog Reset Timer Value***

User can select a value in the range of [10] to [255] seconds when '**WatchDog Reset Timer Unit**' set as [Sec]; or in the range of [1] to [255] minutes when '**WatchDog Reset Timer Unit**' set as [Min].

### ***WatchDog Reset Timer Unit***

The optional settings are: [Sec.]; [Min.].

## **WatchDog Wake-up Timer**

This item support WDT wake-up.

The optional settings are: [Enabled]; [Disabled].

When set as [Enabled], the following sub-items shall appear:

### ***WatchDog Wake-up Timer Value***

User can select a value in the range of [10] to [4095] seconds when '**WatchDog Wake-up Timer Unit**' set as [Sec]; or in the range of [1] to [4095] minutes when '**WatchDog Wake-up Timer Unit**' set as [Min].

### ***WatchDog Wake-up Timer Unit***

The optional settings are: [Sec.]; [Min.].

## **ATX Power Emulate AT Power**

This item support Emulate AT power function, MB power On/Off control by power

---

---

---

supply. Use needs to select 'AT or ATX Mode' on MB jumper at first (refer to **Page 9**, jumper **JAT\_AT1** setting Pin 1&2 of for ATX Mode & Pin 2&3 of AT Mode Select).

▶ **Serial Port Console Redirection**

**COM1**

**Console Redirection**

The optional settings: [Disabled]; [Enabled]. When set as [Enabled], the following sub-items shall appear:

▶ **Console Redirection Settings**

The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.

Press [Enter] to make settings for the following items:

**COM1**

**Console Redirection Settings**

**Terminal Type**

The optional settings: [VT100]; [VT100+]; [VT-UTF8]; [ANSI].

Emulation: VT100: ASCII char set; VT100+: Extends VT100 to support color, function keys, etc.; VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes; ANSI: Extended ASCII char set.

**Bits per second**

Use this item to select serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.

The optional settings: [9600]; [19200]; [38400]; [57600]; [115200].

**Data Bits**

The optional settings: [7]; [8].

**Parity**

A parity bit can be sent with the data bits to detect some transmission errors.

The optional settings: [None]; [Even]; [Odd]; [Mark]; [Space].

Even: parity bit is 0 if the data bits is odd; Odd: parity bit is 0 if num of 1's in the data bits is odd; Mark: parity bit is always 1; Space: Parity bit is always 0; Mark and Space Parity do not allow for error detection.

---

### **Stop Bits**

Stop bits indicate the end of a serial data packet. (A start bit indicates the beginning). The standard setting is 1 stop bit. Communication with slow devices may require more than 1 stop bit.

The optional settings: [1]; [2].

### **Flow Control**

Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a “stop” signal can be sent to stop the data flow. Once the buffers are empty, a “start” signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

The optional settings: [None]; [Hardware RTS/CTS].

### **VT-UTF8 Combo Key Support**

Use this item to enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals.

The optional settings: [Disabled]; [Enabled].

### **Recorder Mode**

With this mode enable only text will be sent. This is to capture Terminal data.

The optional settings: [Disabled]; [Enabled].

### **Resolution 100x31**

Use this item to enable or disable extended terminal resolution.

The optional settings: [Disabled]; [Enabled].

### **Legacy OS Redirection Resolution**

On Legacy OS, the Number of Rows and Columns supported redirection.

The optional settings: [80x24]; [80x25].

### **Putty KeyPad**

Use this item to select FunctionKey and KeyPad on Putty.

The optional settings: [VT100]; [Intel Linux]; [XTERMR6]; [SCO]; [ESCN]; [VT400].

### **Redirection After BIOS POST**

The optional settings are: [Always Enable]; [BootLoader].

When Bootloader is selected, then Legacy Console Redirection is disabled before booting to legacy OS. When Always Enable is selected, then Legacy Console is enabled for legacy OS. Default setting for this option is set to Always

---

Enable.

**Serial Port for Out-of-Band Management/  
Windows Emergency Management Services (EMS)**

**Console Redirection**

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], the following sub-items shall appear:

▶ **Console Redirection Settings**

The settings specify how the host computer and the remote computer (which the user is using) will exchange data. Both computers should have the same or compatible settings.

Press [Enter] to make settings for the following items:

**Out-of-Band Mgmt Port**

The optional setting is: [COM1].

**Terminal Type**

The optional settings: [VT100]; [VT100+]; [VT-UTF8]; [ANSI].

Emulation: VT100: ASCII char set; VT100+: Extends VT100 to support color, function keys, etc.; VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes; ANSI: Extended ASCII char set.

VT-UTF8 is the preferred terminal type for out-of-band management. The next best choice is VT100+ and then VT100.

**Bits per second**

Use this item to select serial port transmission speed. The speed must be matched on the other side. Long or noisy lines may require lower speeds.

The optional settings: [9600]; [19200]; [57600]; [115200].

**Flow Control**

Flow control can prevent data loss from buffer overflow. When sending data, if the receiving buffers are full, a “stop” signal can be sent to stop the data flow. Once the buffers are empty, a “start” signal can be sent to re-start the flow. Hardware flow control uses two wires to send start/stop signals.

The optional settings: [None]; [Hardware RTS/CTS]; [Software Xon/Xoff].

**Data Bits**

The default setting is: [8].

---

*\*This item may or may not show up, depending on different configuration.*

**Parity**

The default setting is: [None].

*\*This item may or may not show up, depending on different configuration.*

**Stop Bits**

The default setting is: [1].

*\*This item may or may not show up, depending on different configuration.*

▶ **PC Health Status**

Press [Enter] to view current hardware health status, make further settings in 'SmartFAN Configuration'.

▶ **SmartFAN Configuration**

Press [Enter] to make settings for SmartFan Configuration:

**SmartFAN Configuration**

**CPUFAN Smart Mode**

The optional settings are: [Disabled]; [Enabled].

When set as [Enabled], the following sub-items shall appear:

**CPUFAN Full-Speed Temperature**

Use this item to set CPUFAN/SYSFAN full speed temperature. Fan will run at full speed when above this pre-set temperature.

**CPUFAN Full-Speed Duty**

Use this item to set CPUFAN/SYSFAN full-speed duty. Fan will run at full speed when above this pre-set duty.

**CPUFAN Idle-Speed Temperature**

Use this item to set CPUFAN /SYSFAN idle speed temperature. Fan will run at idle speed when below this pre-set temperature.

**CPUFAN Idle-Speed Duty**

Use this item to set CPUFAN/SYSFAN idle speed duty. Fan will run at idle speed when below this pre-set duty.

▶ **CPU Configuration**

Press [Enter] to view current CPU configuration and make settings for the following sub-items:



---

## **VT-d**

Use this item to enable or disable CPU VT-d.

The optional settings: [Enabled]; [Disabled].

## **EIST**

Use this item to enable or disable Intel SpeedStep.

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], the following sub-items shall appear:

### **Turbo Mode**

The optional settings: [Disabled]; [Enabled].

### **C-States**

Use this item to enable or disable C-State.

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], the following sub-items shall appear:

#### **Enhanced C-states**

Use this item to enable or disable C1E. When enabled, CPU will switch to minimum speed when all cores enter C-state.

The optional settings: [Disabled]; [Enabled].

### **Max Package C State**

Use this option to controls the max Package C State that the processor will support

The optional settings are: [PC2]; [PC1]; [C0]

### **Max Core CState**

Use this option to controls the max Core C state that cores will support.

The optional settings are: [Fused value]; [Core C10]; [Core C9]; [Core C8]; [Core C7]; [Core C6]; [Core C1]; [Unlimited].

## ▶ **Network Stack Configuration**

Press [Enter] to go to '**Network Stack**' screen to make further settings.

### **Network Stack**

The optional settings are: [Enabled]; [Disabled].

When set as [Enabled], the following sub-items shall appear:

#### **Ipv4 PXE Support**

The optional settings are: [Disabled]; [Enabled].

Use this item to enable Ipv4 PXE Boot Support. When set as [Disabled], Ipv4 boot

---

---

optional will not be created.

### **Ipv6 PXE Support**

The optional settings are: [Disabled]; [Enabled].

Use this item to enable Ipv6 PXE Boot Support. When set as [Disabled], Ipv6 boot optional will not be created.

### **PXE Boot Wait Time**

Use this item to set wait time to press [ESC] key to abort the PXE boot.

### **Media Detect Count**

Use this item to set number of times presence of media will be checked.  
The optional settings range from [1] to [50].

## ▶ **CSM Configuration**

### **Compatibility Support Module Configuraton**

#### **Boot option filter**

This item controls Legacy/UEFI ROMs priority.

The optional settings are: [UEFI and Legacy]; [Legacy only]; [UEFI only].

#### **Network**

This item controls the execution of UEFI and Legacy PXE OpROM.

The optional settings are: [Do not launch]; [UEFI]; [Legacy].

#### **Storage**

This item controls the execution of UEFI and Legacy Storage OpROM.

The optional settings are: [Do not launch]; [UEFI]; [Legacy].

#### **Video**

This item controls the execution of UEFI and Legacy Video OpROM.

The optional settings are: [UEFI]; [Legacy].

#### **Other PCI devices**

This item determines OpROM execution policy for devices other than Network, storage or video.

The optional settings are: [Do not launch]; [UEFI]; [Legacy].

## ▶ **Wake-up Function Settings**

Press [Enter] to make settings for the following sub-items:

### **Wake-up System with Fixed Time**

Use this item to enable or disable system wake-up by RTC alarm.

When this function is enabled, system will wake on the time (hr::min::sec) specified

---

---

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], system will wake on the hour/min/sec specified.

### **Wake-up Hour**

Use this item to 0-23 For example, 3 for 3am and 15 for 3pm.

### **Wake-up Minute**

Use this item to Displays and changes the System Time from the Real-Time Clock. Clock is displayed in 24-hour format.

### **Wake-up Second**

Use this item to Displays and changes the System Time from the Real-Time Clock. Clock is displayed in 24-hour format.

### **Wake-up System with Dynamic Time**

Use this item to enable or disable system wake on alarm event.

System will wake on the current time + Increase minutes.

The optional settings: [Disabled]; [Enabled].

When set as [Enabled], system will wake on the current time + increased minute(s).

### **Wake-up Time Increase**

1 to 60 minute(s)

### **PS2 KB/MS Wake-Up from S3**

The optional settings: [Enabled]; [Disabled].

Use this item to enable or disable PS2 KB/MS wake-up from S3/S4/S5.

**\*\*Note:** PS2 KB/MS Wake-up is affected by ERP function in S4-S5. Please disable ERP before activating this function in S4-S5.

### **PS2 KB/MS Wake-Up from S3-S5**

Use this item to PS2 KB/MS Wake-up is affected by ERP function in S4-S5

**\*\*Note:**Please disable ERP before activating this function in S4-S5

The optional settings: [Disabled]; [Enabled].

### **EXT-USB Power Gating in S4-S5**

Use this item to USB Wake-up is affected by ERP function in S4.

**\*\*Note:**Please disable ERP before activating this function in S4

The optional settings: [Enabled]; [Disabled].

### **INT-USB Power Getting in S4-S5**

Use this item to USB Wake-up is affected by ERP function in S4.

---

**\*\*Note:** Please disable ERP before activating this function in S4  
The optional settings: [Enabled]; [Disabled].

▶ **USB Configuration**

Press [Enter] to make settings for the following sub-items:

**USB Configuration**

**USB Devices: 1 keyboard**

**Legacy USB Support**

The optional settings are: [Enabled]; [Disabled]; [Auto].

**[Enabled]:** To enable legacy USB support.

**[Disabled]:** To keep USB devices available only for EFI specification,

**[Auto]:** To disable legacy support if no USB devices are connected.

**XHCI Hand-off**

This is a workaround for OSeS without XHCI hand-off support. The XHCI ownership change should be claimed by XHCI driver.

The optional settings are: [Enabled]; [Disabled].

**USB Mass Storage Driver Support**

The optional settings are: [Disabled]; [Enabled].

**USB Hardware Delays and Time-outs:**

**USB Transfer Time-out**

Use this item to set the time-out value for control, bulk, and interrupt transfers.

The optional settings are: [1 sec]; [5 sec]; [10 sec]; [20 sec].

**Device Reset Time-out**

Use this item to set USB mass storage device start unit command time-out.

The optional settings are: [10 sec]; [20 sec]; [30 sec]; [40 sec].

**Device Power-up Delay**

Use this item to set maximum time the device will take before it properly reports itself to the host controller.

The optional settings: [Auto]; [Manual].

'Auto' uses default value: for a root port it is 100 ms, for a hub port the delay is taken from hub descriptor.

Select [Manual] you can set value for the following sub-item: '**Device Power-up Delay in Seconds**'.

**Device Power-up Delay in Seconds**

---

The delay range is from [1] to [40] seconds, in one second increments.

▶ **Platform Trust Technology**

**TPM Configuration**

**fTPM**

Use this item to Enable/Disable fTPM


The optional settings are: [Disabled]; [Enabled]

▶ **Intel(R) Ethernet Controller I226-V-XX:XX:XX:XX:XX:XX**

▶ **Intel(R) Ethernet Controller I226-V -XX:XX:XX:XX:XX:XX**

These items show current network brief information.

### 3-8 Chipset Menu



▶ **Uncore Configuration**

Press [Enter] to make settings for the following sub-items:

**GTT Size**

Use this item to select the GTT Size

---

---

The optional settings are: [2MB]; [4MB]; [8MB].

### **DVMT Pre-Allocated**

Use this item to select DVMT 5.0 pre-allocated (fixed) graphics memory size used by the internal graphics device.

The optional settings are: [64M]; [96M]; [128M]; [160M]; [192M]; [224M]; [256M]; [288M]; [320M]; [352M]; [384M]; [416M]; [448M]; [480M]; [512M].

### **DVMT Total Gfx Memory**

Use this item to select DVMT 5.0 total graphics memory size used by the internal graphics device.

The optional settings are: [128M]; [256M]; [MAX].

### **Active LFP**

Use this item to select the active configuration.

The optional settings are: [Disabled]; [LVDS]; [eDP].

**\*\*Note:** When set as **[LVDS]**, user can make further settings in '**LCD Panel Type**' and '**LVDS FW Protect**':

### **LCD Panel Type**

The optional settings are: [800\*480 1ch 18-bit]; [800\*600 1ch 18-bit]; [800\*600 1ch 24-bit]; [1024\*600 1ch 18-bit]; [1024\*768 1ch 18-bit]; [1024\*768 1ch 24-bit]; [1280\*768 1ch 24-bit]; [1280\*800 1ch 18-bit]; [1280\*800 1ch 24-bit]; [1366\*768 1ch 18-bit]; [1366\*768 1ch 24-bit]; [1440\*900 2ch 18-bit]; [1440\*900 2ch 24-bit]; [1280\*1024 2ch 24-bit]; [1680\*1050 2ch 24-bit]; [1920\*1080 2ch 24-bit];

### **LVDS FW Protect**

Use this item to set LVDS FW Protect function.

The optional settings are: [Enabled]; [Disabled].

**\*\*Note:** When set as **[LVDS]** or **[eDP]**, user can make further settings in '**GMCH BLC Control**':

### **GMCH BLC Control**

Use this item to set backlight control settings.

The optional settings are: [PWM-Inverted]; [PWM-Normal].

### **Primary IGFX Boot Display**

Use this item to select the video device which will be activated during POST. This has no effect if external graphics present. Secondary boot display selection will appear based on your selection.

---

*The optional settings are: [Auto]; [HDMI1]; [HDMI2].*

### **Secondary IGFX Boot Display**

Use this item to select Secondary Display Device.

The optional settings are: [Disabled]; [HDMI1]; [HDMI2]

### **Memory Configuration**

The working memory information will be on display.

## ▶ **South Cluster Configuration**

### ▶ **PCI Express Configuration**

Press [Enter] to make settings for the following sub-items:

#### **PCI Express Configuration**

##### **Peer Memory Write Enable**

The optional settings: [Disabled]; [Enabled].

##### **Compliance Mode**

The optional settings: [Disabled]; [Enabled].

### ▶ **SATA Configuration**

Press [Enter] to make settings for the following sub-items:

#### **SATA Controller**

The optional settings are: [Enabled]; [Disabled].

When set as [Enabled], the following items shall appear:

#### **SATA Mode Selection**

Use this item to determine how SATA controller(s) operate.

The default setting is: [AHCI].

#### **SATA Port**

##### **SATA Port**

Use this item to enable or disable each SATA port.

The optional settings: [Disabled]; [Enabled].

#### **M.2**

##### **M.2**

Use this item to enable or disable M.2 SATA port.

The optional settings: [Disabled]; [Enabled].

---

### **HD-Audio Support**

Use this item to enable or disable HD-Audio Support.

The optional settings are: [Disabled]; [Enabled].

### **SCC eMMC Support**

Use this item to enable or disable SCC eMMC Support.

The optional settings are: [Disabled]; [Enabled].

**\*\*Note:** *'SCC eMMC Support' item is optional for boards with EMMC integrated.*

### **eMMC Max Speed**

Use this item to select the eMMC max speed allowed.

The optional settings are: [HS400]; [HS200]; [DDR50].

**\*\*Note:** *'eMMC Max Speed' item is optional for boards with EMMC integrated.*

### **System State after Power Failure**


Use this item to specify what state to go to when power re-applied after a power failure (G3 state).

The optional settings are: [Always On]; [Always Off]; [Former State].



---

## 3-9 Security Menu



Security menu allow users to change administrator password and user password settings.

### Administrator Password

If there is no password present on system, please press [Enter] to create new administrator password. If password is present on system, please press [Enter] to verify old password then to clear/change password. Press again to confirm the new administrator password.

### User Password

If there is no password present on system, please press [Enter] to create new administrator password. If password is present on system, please press [Enter] to verify old password then to clear/change password. Press again to confirm the new administrator password.

---

---

▶ **Secure Boot**

Press [Enter] to make customized secure settings:

**Secure Boot Control**

The optional settings are: [Disabled]; [Enabled].

Secure Boot can be enabled if 1. System running in user mode with enrolled Platform Key (PK); 2. CSM function is disabled.

**Secure Boot Mode**

The optional settings are: [Standard]; [Custom].

Set UEFI Secure Boot Mode to Standard mode or Custom mode. This change is effective after save. After reset, this mode will return to Standard mode.

*\*When set as [Custom], user can make further settings in 'Key Management'.*

▶ **Key Management**

This item enables experienced users to modify Secure Boot variables, which includes the following items:

**Provision Factory Default Keys**

This item is for user to install factory default secure boot keys when system is in Setup Mode.

The optional settings are: [Disabled]; [Enabled].

▶ **Enroll All Factory Default Keys**

This item forces system to User Mode-install all Factory Default keys.

▶ **Save all Secure Boot Variables**

This item will save NVRAM content of all Secure Boot variables to the files (WFI\_SIGNATURE\_LIST data format) in root folder on a target file system device.

▶ **Platform Key (PK)/Key Exchange Keys/Authorized Signature/Forbidden Signature/ Authorized TimeStamps/OS Recovery Signatures**

Use this item to enroll Factory Defaults or load the keys from a file with:

1. Public Key Certificate in:


- a) EFI\_SIGNATURE\_LIST
- b) EFI\_CERT\_X509 (DER encoded)
- c) EFI\_CERT\_RSA2048 (bin)
- d) EFI\_CERT\_SHA256 (bin)

---

## 2. Authenticated UEFI Variable

\*\*Key: Vendor, Custom, Mixed, Test(\*) modified from Setup menu

### 3-10 Boot Menu



#### **Setup Prompt Timeout**

Use this item to set number of seconds to wait for setup activation key.

#### **Bootup Numlock State**

Use this item to select keyboard numlock state.

The optional settings are: [On]; [Off].

#### **Quiet Boot**

The optional settings are: [Disabled]; [Enabled].

#### **Boot Option Priorities**

#### **Boot Option #1/ Boot Option #2/ Boot Option #3**

Use this item to Sets the system boot order.

---

---

---

The optional settings are: [Windows Boot Manager (MMC- BJTD4R)]; [MMC- BJTD4R]; [UEFI: Built-in EFI Shell]; [Disabled]


### Hard Drive BBS Priorities

Use this item to set the order of the legacy devices in the available group  
Press [Enter] to make settings for the following sub-items:

#### Boot Option #1

Use this item to Sets the system boot order  
The optional settings are: [MMC- BJTD4R]; [Disabled].

## 3-11 Save & Exit Menu



### Save Changes and Reset

This item allows user to reset the system after saving the changes.

### Discard Changes and Reset

This item allows user to reset the system without saving any changes.

### Restore Defaults

Use this item to restore /load default values for all the setup options.

### Save as User Defaults

---

---

Use this item to save the changes done so far as user defaults.

**Restore User Defaults**

Use this item to restore defaults to all the setup options.

**Boot Override**

The available options here are dynamically updated and make system boot to any boot option selected.

**Windows Boot Manager (MMC- BJTD4R)**

Use this item to save configuration and reset

**MMC- BJTD4R**

Use this item to save configuration and reset

**Launch EFI Shell from filesystem device**

Use this item to launch EFI shell application (shell.efi) from one of the available filesystem device.